

Receiver/Servo Compatible Table

Product Name		RX-491				RX-482/RX-472/RX-47T RX-481/RX-481W/RX-471/RX-471W RX-471 Dual ID/RX-461/RX-462 SV PLUS Series			RX-451R		RX-451/381/380		RX-391W	RX-371W RX-37W
		SUR	SSR	SHR	NOR	SSR	SHR	NOR	SSR	SHR	SHR	NOR	-	-
Defutal Servo	PGS SERVOS	○	○	○	○	○	○	○	○	○	○	○	○	○
	SRG SERVOS	×	○	○	○	○	○	○	○	○	○	○	○	○
	Digital ERG SERVOS SDX / HVS SERVOS ERS / ERB SERVOS	×	×	○	○	×	○	○	×	○	○	○	○	○
Analog Servo	Hyper ERG SERVOS RS-995 / SX-165T SPEC SERVOS SX SERVOS SRM SERVOS	×	×	×	○	×	×	○	×	×	×	○	○	○

Receiver/ESC Compatible Table

Product Name		RX-491				RX-482/RX-472/RX-47T RX-481/RX-481W/RX-471/RX-471W RX-471 Dual ID/RX-461/RX-462			RX-451R		RX-451/381/380		RX-391W	RX-371W RX-37W
		SUR	SSR	SHR	NOR	SSR	SHR	NOR	SSR	SHR	SHR	NOR	-	-
SUPER VORTEX Gen 2 PRO / Gen2 / STOCK SUPER VORTEX ZERO / TYPE D / SPORT HX-12 STOCK SPECIAL HV-01 / HV-02		×	○	○	○	○	○	○	○	○	○	○	○	○
HV-15/HV-10 SV-08 F2500		×	×	○	○	×	○	○	×	○	○	○	○	○
SBL-01/SBL-02/SBL-03CR F3300/F3000/F2200/F2000 BL-RACER/BL-FORCE/BL-SPORT		×	×	×	○	×	×	○	×	×	×	○	○	○

- RX-451R is compatible with SSR/SHR mode. RX-451R is NOT compatible with NOR mode
When using SRG/PGS Servos with SSR mode, the servo will be very quick response than using SHR mode

- (*1) Automatically set SSR mode binding with RX-451R by M12S, M12S-RS, M12, EXZES ZZ, EXZES Z, MT-4, MT-4S, MT-S transmitter set SHR mode (display SHR on transmitter)
- (*2) Automatically set SHR mode binding with RX-451R by M12S, M12S-RS, M12, EXZES ZZ, EXZES Z, MT-4, MT-4S, MT-S transmitter set NOR mode (display NOR on transmitter)
- (*3) In case of using 7.2 V compatible servos, transmitter (Without M12S, M12S-RS, M12, EXZES ZZ, EXZES Z, MT-4, MT-4S, and MT-S) cannot work fail safe mode
It set 3.5V - 5.0 V and cannot change range of voltage. Please take care of changing battery in case of using Li-Po battery. We could not gurantee in this case
- (*4) Receiver did not compatible with 7.4 V. Please use 6.0 V for the reciever
- (*5) SHR/SSR mode only compatible with degital servos. Using with the modes, the analog servos will be broken. Please do NOT use analog servos by the modes
- (*6) Cannot use SV-PLUS series on board with receiver